HANDHELD FABRIC STEAMER

콘에어 스팀 & 프레스 퍼펙트 스티머

INSTRUCTION
BOOKLET
사용설명서

CONAIR®

GS51K

CONAIR HANDHELD FABRIC STEAMER

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING
KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children.
Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. Do not use the unit if it has fallen or if it appears to be damaged.
5. Do not leave the unit unattended when it is plugged in or switched on.
6. Unplug the unit immediately if you have problems when using it.
7. Do not use any accessories other than those recommended by manufacturer.
8. Unplug the unit after each use and before filling or cleaning it.
9. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
10. Allow the unit to cool before storing.
11. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.
12. When emitting steam, this appliance may cause burns if it is used too close to the skin or eyes, or if it is used incorrectly. To reduce the risk of contact with hot water emitting from the steam vents, test appliance before use by holding it away from the body.
13. Do not steam garments while on a person.
14. Burns could occur from touching hot metal parts, hot water or steam. Use care when you turn steam appliance upside down.
15. Do not operate steamer without correctly filling the water container. Only use clean cold water for filling this appliance. We recommend the use of distilled or purified cold water only.
16. Use of an extension cord is not recommended. If an extension cord is absolutely necessary, a 13-ampererated cord should be used. Cord rated for less amperage may overheat. Care should be taken to arrange the cord so that it cannot be pulled or tripped over.
17. Never yank cord to disconnect from outlet, instead, grasp plug and pull to disconnect.
18. Use with caution when carrying steamer as it contains hot water.

NOTE: When first using the device, it is recommended to test on an old cloth or operate the steamer for 5 minutes , as there may be sediment left from the manufacturing precess or transportation. Then unplug the unit and allow it to cool. Empty container and refill before actually using.

HOUSEHOLD USE ONLY

FILLING INSTRUCTIONS

1. Make sure the unit is unplugged.
2. Stand the unit on a table and grasp with one hand.
3. With other hand, pull the reservoir out, away from the steamer body.
4. Open the inlet cover and fill the reservoir with water (preferably distilled, which can be found in grocery stores). We recommend that you use distilled water only as this will prevent mineral deposits in the boiler that can reduce performance or clog the water system.
5. Close the inlet cover and return the reservoir to its place, making sure that it snaps in place and is secure.

GET TO KNOW YOUR STEAMER

OPERATING INSTRUCTIONS

1. Fill water reservoir with preferably distilled water (See Filling Instructions.)
2. Plug the unit into the electrical outlet.
3. Press the On/Off button to turn steamer on.
4. The blue and red READY light will illuminate and begin blinking. Allow 35 seconds for the unit to warm up. The appliance is ready to use when the red light stops blinking and remains solid. **NOTE:** Before first use or when the unit has not been used for a long period of time, it will be necessary to prime (i.e., fill with water) the internal tank while the steamer prepares to steam. You may hear a small tapping noise during the heat-up process; this is normal.
5. Your steamer has 3 options for steam: To choose steam setting press the +/- Mode button. One light indicates Low mode for delicate fabrics or for freshening lightly wrinkled garments. Two lights indicate Medium mode for everyday cottons and polyester fabrics with moderate wrinkles. Three lights indicate High Turbo mode for thicker fabrics and heavily wrinkled fabrics.

6. Pointing the steam jets away from you, and anyone else in the room, press the Steam button to release steam. **Always have steam facing away from you or anyone in the room.**
7. To stop the flow of steam, press the steam button.
8. To off the device, press the ON/OFF button for 3 seconds and unplug when it is not in use.

USING 2-IN-1 ATTACHMENT

With the garment steamer off and cool, snap the silicone band attachment over the steam head, ensuring it is firmly affixed. At this point, the silicone band can be used, or you can choose to affix the bristle brush insert into the channel on the top of the silicone band attachment. Press the ON/OFF button to turn steamer on. Note: Only one function of the 2-in-1 attachment can be used at a time.
CAUTION: Use extreme care when changing the attachments after the unit has been in use, as the steam head will continue to be hot.

AUTO SHUTOFF FEATURE

When the machine is powered on continuously for 15 minutes, it will enter the automatic power-off mode. Power indicator light will flash to indicate shutoff.

STEAMING TIPS FOR PRESSING

CAUTION: First, test unit on an inconspicuous area of the item to be steamed, using the regular Steam setting to ensure fabric can tolerate the effects of steam. If there is no evidence of damage, you can proceed to use the steamer on that item.

1. To prepare your fabric for steaming, brush it with the brush attachment. This will loosen the fibers and allow better steam penetration.
2. Hang your garment or fabric. **NOTE:** Avoid using metal clothes hangers, if possible. **CAUTION: If hanging garment on a door while steaming, be careful not to damage the door with steam.**
3. Pass the steam jets just above the fabric where the wrinkles are. It may take a few passes to remove the wrinkles completely.
4. For heavier fabrics or severely wrinkled fabrics, you may position the steamer head directly on the fabric for a few seconds to remove wrinkles. Be cautious when working with delicate fabrics. **NOTE:** Do not continuously hold steamer over an area or touch steamer jets directly to fabric for more than a few seconds, as this can cause damage, including shrinkage, melting, or color shift on certain types of material.
5. After use, turn unit off by depressing the On/Off button. Empty any remaining water from the tank to avoid leakage. With dry hands, unplug your garment steamer from the outlet. **BE SURE TO PRESS THE ON/OFF BUTTON PRIOR TO UNPLUGGING THE UNIT.**

CLEANING/STORING/MAINTENANCE

- After use – wait for it to cool down before cleaning and then remove any water left in water tank.
- Allow the water tank to dry thoroughly.
- Keep this garment steamer out of reach of babies and children.
- Do not wrap the power cord around the unit and ensure it is stored without twisting or folding it.
- For the best performance, limescale should be removed from time to time.

Note: Minerals in water will vary in different areas. To insure continued operation of the steamer, use only purified/distilled water, never store without cleaning and removing excess water from the reservoir and water container.

ONE YEAR LIMITED WARRANTY

This Conair Appliance is guaranteed for consumer use for one year. This guarantee is no longer valid in case of alteration or repair by any unauthorized persons and only covers defects under normal use from the date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, it will be repaired or replaced under Consumer Dispute Settlement Regulation of Fair Trade Commission.

THE DATE CODE MENTIONED

WWYYXXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.

CONAIR KOREA CUSTOMER SERVICE:

Conair Korea Trading Limited
Customer Center: 1899-0209
A/S Center: www.fillelec.co.kr

GS51K **IB-21/102**

CONTINENTAL CONAIR LIMITED
CHINA CREATIVE DEPARTMENT

Date	6/29/21
Customer	CKTL
Model No.	GS51K
Description	IB
Job No.	
Reference No.	IB-21/102
Revision No.	9
Color	1C+1C(Black)
Open Size	552mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	Betty Bai
Approved by	Ken Xiong/ Jay Joen
Vendor	Heiger
Supplier	

折叠方法
Folding method:
12 pages (6 x 2)

콘에어 스팀 & 프레스 퍼펙트 스티머

주요 안전 사항

제품 사용 시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수하십시오.

사용 전 반드시 사용설명서를 숙지하여 주십시오.
물에 접촉하거나 빠뜨리시면 안됩니다.

안전주의

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용하기에 위험 하오니 어린이의 손이 닿지 않는 안전한 곳에 두십시오. 유아 및 어린이 침대, 유모차, 하이체어, 어린이 놀이 지역 안에서는 절대 사용하지 마십시오. 얇은 막의 필름이 코나 입에 붙어 질식을 유발할 수 있습니다. 포장재는 장난감이 아닙니다.

경고: 이 제품을 욕조, 샤워기, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.

1. 부득이 욕실 등 물이 있는 곳에서 사용하실 경우, 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 본 제품이 물 가까이에 있을 경우 위험할 수 있습니다. 보다 안전한 사용을 위하여 욕실에 누전차단기를 설치하시기를 권장하며 욕실의 잔류 전류 용량은 30mA 이하여야 합니다. 욕실 등에서 사용시 위 사항을 참조하여 전문가와 상의하시기 바랍니다.
2. 본 제품을 절대로 물 또는 다른 액체에 담그거나 빠뜨리지 마십시오.
3. 전원코드가 손상된 경우 사용을 중단하시고 위험 방지를 위해 반드시 서비스 센터에 연락하여 수리를 받으셔야 합니다.
4. 제품을 떨어뜨리셨거나 제품에 손상 및 파손이 보이는 경우 절대 사용하지 마십시오.
5. 스위치를 켜 두거나 플러그를 꽂아둔 상태에서 자리를 비우지 마십시오.
6. 사용 중 문제가 생기면 바로 플러그를 뽑으십시오.
7. 본 매뉴얼에 기술된 목적으로만 본 제품을 사용하시고 제조사에서 권고하지 않은 부속품을 사용하지 마십시오.
8. 물통에 물을 채우거나 제품을 세척할때에는 반드시 제품의 전원을 끄고 전원 플러그를 뽑으십시오.
9. 본 제품은 영유아, 어린이, 심신박약자, 심신상실자, 정신질환자, 사용 경험이 없거나 사용이 미숙한 사람 등에 의해 사용되어서는 안되며, 사용시엔 반드시 안전을 책임질 수 있는 보호자의 지도하에 사용하도록 합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별한 주의 바랍니다.
10. 제품 사용이 끝나면 열판 및 제품이 완전히 식은 후 보관하십시오.
11. 코드 손상을 막기 위해 코드를 제품에 감지 마시고, 꼬이거나 접히지 않도록 보관하십시오.
12. 뜨거운 스팀이 방출되어 화상의 위험이 있으니 사람이나 동물의 피부나 눈을 향해 사용하지 마십시오. **주의:** 사용 중 스팀 분출구를 통해 뜨거운 스팀이 나오므로 가능한 몸에서 멀리 떨어져 사용하십시오.
13. 입고 있는 옷을 스팀 다림질 하지 마십시오.
14. 스팀, 가열된 물, 금속 부분으로부터 화상을 입을 수 있습니다. 제품을 거꾸로 들면 뜨거운 물이 역류하여 화상의 위험이 있습니다.
15. 물통을 제대로 장착한 후 사용하십시오. 본 제품 사용 시 차가운 정수된 물 혹은 정제수 사용을 권장합니다. 수돗물 사용 시 석회가 쌓여 제품의 성능이 저하될 수 있습니다.
16. 멀티탭 등 전원 연결선 사용은 권장하지 않습니다. 멀티탭을 사용할 수 밖에 없을 경우는 13암페어 이상의 제품을 사용하시기 바랍니다.
17. 전원코드 선의 중간부를 잡아당겨 플러그를 뽑지 마십시오.
18. 작동 중에는 내부의 물이 가열되어 뜨거우니 화상에 주의하십시오.

주의: 구매 후 처음으로 사용 전 반드시 옷 안쪽의 보이지 않는 곳 혹은 입지않는 옷 등에 스팀을 분사하여 옷감의 이염 및 손상 여부를 확인 하거나 제조 및 배송과정에서 생긴 불순물이 나오지를 확인 하신 후 사용하시기 바랍니다.
또한 배송 중 온도차로 인해 물통에 물방울이 맺혀 있을 수 있으나 제품이상이 아닙니다.

본 제품은 가정용입니다.

물통 채우는 방법

1. 스티머의 전원이 꺼져있고 전원 코드가 플러그에서 뽑혀있는지 확인 하십시오.
2. 물통 윗면의 양 모서리를 잡아주십시오.
3. 물통을 앞으로 당겨 본체에서 분리하십시오.
4. 물통 상단의 주입구를 열어 적당량의 물을 채워 주십시오. **주의:** 지역에 따라 수돗물에 석회가 다량 함유되어 제품의 성능 및 수명에 영향을 줄 수 있으니, 정수된 물의 사용을 권장합니다

5. 적당량의 물을 채워 물통 상단의 주입구를 잘 막고, 본체에 일착시킨 후, 물통을 딸깍소리가 날 때까지 본체에 완전히 부착하여 주십시오. 사용 전 제대로 부착되었는지 반드시 확인하십시오.

제품 설명

스팀 다리미 사용법

주의: 구매 후 처음 사용할 때에는 제조 및 배송 과정에서 생긴 불순물이 나올 수 있으니 입지 않는 옷이나 오래된 천, 혹은 옷감 안쪽의 보이지 않는 곳에 테스트하여 이염 및 손상 여부를 확인하신 후 사용하십시오.

1. 사용 전 물통에 적당량의 물을 채워 주십시오.
2. 전원 코드를 플러그에 꽂아 주십시오.
3. 스티머 윗면의 전원버튼을 눌러 주십시오
4. 전원버튼을 누르면 예열 표시등이 깜빡입니다. 35초 후 예열이 완료되면 표시등이 깜빡임을 멈춥니다. **주의:** 제품을 처음 사용하시거나 장기간 미사용 후 작동하게 될 경우 예열 시간이 추가로 더 걸리거나 내부의 보일러가 가열되며 소리가 날 수 있으나 제품 이상이 아닙니다.
5. 본 스티머는 3단계의 스팀 설정이 가능합니다. 제품 뒷면의 +/- 버튼을 눌러 스팀세기를 설정하십시오. 1단계(1개의 적색LED) - 2단계 (2개의 적색LED) - 3단계 (3개의 적색LED)이며, 3단계가 가장 높은 스팀 세기 입니다. 스팀 분출구를 사용자를 포함한 사람이나 동물이 없는 곳으로 향하게 한 후 사용하십시오. **사용 예:** 1단계에서는 섬세한 옷감에 적합합니다. 3단계에서는 겨울 외투, 이불 등 두꺼운 섬유에 적합합니다.

스팀 다리미 사용 시에는 항상 화상에 주의하시기 바랍니다.

6. 원하는 스팀단계 설정 후 스팀 버튼을 누른 후 스팀 분사구가 옷감이나 패브릭에서 약 3cm정도 떨어진 상태에서 계속해서 움직이며 스팀이 고르게 닿을 수 있도록 하십시오. **스팀이 나오는 도중에는 절대로 사람이나 동물을 향하지 마십시오.**
7. 사용 중 스팀을 멈출 때에는 스팀 버튼을 누르십시오.
8. 사용 후에는 전원버튼을 3초간 길게 눌러 전원을 끄시고 제품을 충분히 식힌 후 물통의 물을 비워 말린 후 어린이의 손이 닿지 않는 안전한 곳에 보관하십시오.

2-in-1 액세서리 사용법

경고: 절대로 액세서리를 스티머를 사용 하는 도중 부착하거나 교체하지 마십시오. 또한 전원이 꺼져있는 상태라도 화상 위험이 있으니 스티머 헤드가 충분히 식었는지 반드시 확인한 후 액세서리를 부착 혹은 교체 하십시오.

1. 실리콘 브러시: 다림질을 쉽게 할 수 있도록 옷감을 팽팽하게 당겨줍니다.
2. 섬유 브러시: 두꺼운 코트나 섬유의 결을 정리하고 먼지를 제거하여 스팀이 깊숙이 침투할 수 있도록 합니다.

모든 액세서리를 한번에 끼워서도 사용이 가능합니다.

자동 전원차단

본 스티머는 15분 이상 전원이 켜있는 경우 자동으로 전원 차단 및 대기 모드로 전환됩니다. 대기 모드 중에는 전원 차단 중임을 알리기 위해 후면의 전원 표시등이 깜빡입니다.

사용 팁

주의: 구매 후 처음 스팀 다리미를 사용하시는 경우 옷감이 스팀에 의해 손상 및 이염되지않는지 옷감 안쪽의 눈에 띄지 않는 곳에 테스트 하여 손상 및 이염 여부를 확인 하신 후 스티머를 사용하십시오.

1. 섬유의 조직이 두껍고 모가 긴 경우 패브릭 브러시로 결을 정리하여 스팀이 효과적으로 작용할 수 있게 해주십시오.
2. 스팀 다림질이 필요한 옷이나 패브릭을 옷걸이에 걸어 준비하십시오 **주의:** 강력한 스팀으로 부식되거나 옷감에 손상을 줄 수 있으니 철제 옷걸이의 사용은 피하여 주십시오.
3. 스티머를 옷감의 위에서 아래 방향으로 움직이며 구김이 있는 옷감 위로 스팀이 고르게 분사되게 하십시오. 주름이 깊은 경우 위 동작을 수차례 반복하십시오. **주의: 옷감을 방문이나 옷장 문에 걸어 다림질 할 경우 고온의 스팀으로 후면의 방문 및 옷장 문이 손상 될 수 있으니 주의 하십시오.**
4. 두껍고 거친 소재의 직물이나 주름이 깊은 옷감에는 수초간 스팀이 닿도록 하시고 여러 차례 움직이며 다림질을 반복하십시오. **주의:** 실크나 스카프같이 얇은 천에는 한 곳에 오래 스팀을 분사할 경우 수축, 이염, 늘어붙음 등의 손상을 유발할 수 있으니 주의하십시오.
5. 사용 후에는 전원 버튼을 눌러 완전히 전원을 꺼주십시오. 그 후 마른 손으로 플러그에서 전원 코드를 뽑은 후 열판 및 제품이 충분히 식은 뒤 물통에 남아있는 물을 완전히 비우고 말린 후 보관 하십시오.

세척/보관/유지

- 사용 후 스티머 열판이 완전히 식은 후 물통을 꺼내 남은 물을 모두 버려 주십시오.
- 물통에 물기가 남지 않도록 완전히 말려 주십시오.
- 보관시에는 어린이나 노약자의 손이 닿지 않는 곳에 놓아 주십시오.
- 제품에 전원 코드를 감아서 보관하지 마십시오.
- 스팀 다리미의 성능 유지 및 열록/물때 방지를 위해 수시로 물때를 제거해 주십시오.

참고: 일반 수돗물의 경우 다량의 석회를 포함하고 있을 수 있으니 다리미의 성능 유지 및 사용 수명 연장을 위해 정수된 물의 사용을 권장하며 보관 시에는 항상 잔여 수분을 제거하십시오.

1년 보증기간

본 제품의 보증기간은 1년입니다. 본 제품은 공정거래위원회 고시 소비자분쟁해결기준에 의거 교환 또는 보상받을 수 있으며 정상적인 제품 사용 도중 발생한 제품 하자의 경우에만 보상이 가능합니다.

제조일 표기

제조일은 본 제품에 WWYYXXX형태로 표기되어 있습니다. W는 '주', Y는 '년도 ' 를 나타냅니다.

A/S 및 제품 문의

콘에어코리아트레이딩 주식회사
홈페이지: www.conair.co.kr
소비자 상담실: 1899-0209
A/S 문의: www.fillelec.co.kr